



SMART iD ALARM CONTROL SYSTEM

OPERATING INSTRUCTIONS

This information is relevant to systems fitted
with Issue 1.1 (or later) Software


Castle Care-Tech Ltd.

1. Introduction	Page 2
1.1. Using the System - Summary	3
1.1.1. Setting the System	3
1.1.2. Unsetting the System	3
1.1.3. Silencing an Alarm	3
1.2. Keypad Alerts	3
2. Terms Used	4
2.1. The Display	5
2.2. The Keypad	5
2.3. Operating Codes	6
2.4. The Tagset or Keyswitch	6
2.5. Levels of setting	6
3. Using the System	7
3.1. Setting the System	7
3.1.1. Setting the System with the Keypad	7
3.1.2. Setting the System using the Tagset or Keyswitch (if fitted)	8
3.2. Omitting Individual Zones	8
3.3. Unsetting the System	9
3.3.1. Unsetting the system with the Keypad	9
3.3.2. Unsetting the system with the Tagset or Keyswitch (if fitted)	9
3.4. Action Following an Alarm	9
3.4.1. Cancelling a daytime alarm	9
3.4.2. Unsetting following an Alarm	10
3.5. Chime	10
4. Manager Functions	11
4.1. Accessing Manager Functions	11
4.2. Setting User Codes	11
4.3. Setting the Manager Code	12
4.4. Testing the System	12
4.4.1. Walk Test	12
4.4.2. Bell Test	13
4.5. Displaying System Logs	13
4.5.1. Activation Records	14
4.5.2. An Alarm or Trouble record	14
5. System Faults	15
5.1. System Tamper Fault (F-1)	15
5.2. System Voltage Fault (F-3)	15
5.3. Keypad Alarm (F-7)	15

1 INTRODUCTION

The Care-Tech Smart iD Alarm control unit has been designed and manufactured in England to provide the facilities necessary to form the heart of a sophisticated alarm system for the protection of persons and property. Many of the facilities are programmed by the installing company, who will be able to advise you on the availability of certain of the features referred to in this manual.

The system consists of the Smart Keypad, from which the system is controlled, wired to a Power Supply unit and Smart Sounder via an 'Intelligent Highway.' Detectors, and optional setting and unsetting points, are wired to this same 'highway.'



The system is powered from the mains supply, and is fitted with a rechargeable battery to ensure that the system continues to function normally, for a minimum of eight hours, during a mains power failure.

Before attempting to use the alarm system, please read and thoroughly familiarise yourself with these instructions.

1.1 Using the System - Summary

1.1.1 Setting the System

Before setting the system, verify that the system display shows 'd', as illustrated on page 2. Setting is performed by use of the 'function' keys as follows:

A# will switch on the CHIME mode, to alert you if someone enters a door or room designated as 'chime.' The display will show the 'Full stop' illuminated whilst 'chime' mode is selected. The chime can be switched off by keying in A# again.

B# will setting the system in the 'PART SET B' mode - designed for use when you go to bed. (B#* will set the system silently.)

C# will setting the system in the 'PART SET C' mode, for example to protect a garage or other separate area. (C#* will set the system silently.)

D# will set the entire system, for use when the premises are unoccupied.

There is NO indication on the display when the system is set.

1.1.2 Unsetting the System

The system is unset from the above modes by using your full four-digit code, followed by #.

1.1.3 Silencing an Alarm

In the event of an alarm, this may be silenced by entering your four-digit code, followed by #

1.2 Keypad Alerts

The Smart iD Alarm provides the following unique functions, if programmed to be available

1* will start the 'JUST-IN-CASE' timer that will run for a pre-set period. If not cancelled by a valid user code, the alarm will sound. A brief pulsing tone will act as a reminder that the timer is running.

If you are nervous about opening the door to strangers, etc. this timer can be set first to provide additional security.

7* will cause a FIRE ALARM to sound (an intermittent alarm tone).

3 & 9 pressed simultaneously will cause a Personal Attack Alarm to sound.

These alarms are silenced by keying in your four-digit code and #

2 Terms Used

Certain terms used to describe features and operation of the system may be unfamiliar, the principal ones are as follows:

DAY MODE	The 'normal' state of the alarm system whilst the premises are occupied, and the alarm switched 'OFF.' 'Personal Attack' and system tamper facilities remain functional. Also called 'UNSET' or 'OPEN'
SWITCH ON	The action of activating, or 'SETTING' the alarm system, whether by use of the keypad, keyswitch or Tagset.
SET	The condition of the alarm system when armed, after the switching on process has been completed - ie after the completion of the exit time. Also known as 'CLOSED.'
FULL SET	The condition of the alarm when the entire system is set
PART SET	The condition of the alarm system when pre-programmed portions of the system only are armed - for example setting the system at night whilst still in the premises.
EXIT TIME	The time delay permitted after switching the system on and before it becomes armed, during which you must leave the premises, and close the final exit door.
ENTRY TIME	The time delay permitted by the system after entering by the authorised route, and during which the system must be switched off, or an alarm will sound.
ENTRY-EXIT ROUTE	The portion of the alarm system linked to the Exit and Entry timers, through which exit and entry must be made.
ZONE or CIRCUIT	A division of the system which is separately identified in the indications at the control.
ZONE or CIRCUIT FAULT	Condition of a zone when the detector is not clear, preventing the system from being 'set', eg a door open.
ZONE OMISSION	The facility to disable an individual zone (or zones) whilst setting the system
SYSTEM FAULT	An incorrect electrical condition which may impair the correct operation of the system.
TAMPER	A fault exists in the wiring, or securing of the housing of part of the system, preventing normal operation.
PERSONAL ATTACK (PA)	An alarm generated deliberately, to summon assistance if being attacked, operative whether system is set or not.

2.1 The Display

The 7-segment LED display indicates the condition of your alarm system. This will clearly show any information requiring your attention, as indicated in these instructions, as follows:

'Normal' Indications		'Fault' Indications	
d	System in 'day' mode		
d .	'Chime' is enabled	Figure (0-9)	A fault or alarm has originated on the zone numbered.
- (single 'bar')	Code accepted, whilst FULL setting the system	F-1 (alternating)	Keypad tamper fault
- flashing	As above, whilst being PART set.	F-3 (alternating)	System voltage fault
. flashing	During exit time	F-7 (alternating)	PA or Fire Alarm generated by keypad.
Green LED (on keypad)	Power supply healthy	Green LED flashing	Battery fault detected

You will observe other indications whilst using the Manager Functions of the system, as itemised in Section 8 of this manual.

2.2 The Keypad

The four Function keys (A,B,C,D) allow for setting the system in the various modes available. The 10 numeric keys are for entering your code for unsetting the system, or entering other information when required. The # (YES) and * (NO) keys allow confirmation or cancelling of codes entered. Always enter your code carefully and deliberately, never leaving more than 3 seconds between presses, or the system will reset itself.

The keys are back-lit to simplify use in poor lighting conditions.

2.3 Operating Codes

There are three levels of access to the system as follows:

Code	Details of use	Pre-set	To change
USER	4 different codes may be programmed These enable the system to be set and unset.	1234	See 8.2
MANAGER	A single code must be programmed. This provides access to the 'Manager' menu to permit additional functions to be used.	2222	See 8.3
ENGINEER	A single code is available to the installing company engineer to access the programming facilities of the system		

2.4 The Tagset or Keyswitch

The tagset, or keyswitch, if fitted, provide alternatives to the keypad for setting, unsetting or resetting the system. Each tagset or keyswitch will set the system in Full OR Part B, as installed. They may be used interchangeably with the keypad.

2.5 Levels of setting

The control is designed to enable the system to be used in a variety of ways to maximise your security. These are:

- FULL SET** The entire system is armed, and in the event of an intrusion, an alarm will be sounded.
- PART SET B** A pre-programmed portion of the system only is set, to enable, for example, the downstairs to be set at night whilst the occupants are asleep. The system may be programmed to provide a reduced level of warning outputs in this mode - eg no external sounder.
- PART SET C** A pre-programmed portion of the system is armed to provide warning of intruders whilst the premises are occupied during the day, eg the upstairs may be monitored. The alarm warning will be the same as for 'Part' set.
- CHIME** Provides a simple 'Chime' warning if someone enters a zone allocated as 'chime'

Note that the areas pre-programmed for PART SET B, PART SET C and CHIME may all be different, or overlap.

3 Using the System

3.1 Setting the System

3.1.1 Setting the System with the Keypad

Step	Action	Response	Display
a	Verify that all doors, etc. are closed, and that 'd' is displayed		'd'
b	Enter the appropriate function key, followed by # .	Acceptance of code will be confirmed by display showing a single 'bar' (flashing if PART set). After a few seconds, a steady tone will commence.	'-' (flashing if PART set)
c	Leave the building by the specified route. To set the system silently (eg at night if part of the family is asleep): press * within 2 seconds of completing step b.	Continuous tone sounds. Tone will be aborted.	'-' (flashing if PART set)
d	If a detector is in fault condition, eg a door is opened If this detector is part of the exit route, you may continue, ensuring that all doors are closed behind you; otherwise correct the fault before attempting to leave the building	The tone will become intermittent When closed, the tone will become steady once more.	The display will indicate the number of the zone in fault condition
e	Close the Final exit door	Tone will cease when timer expires	Blank
f	The system may be programmed for the external strobe to flash briefly to confirm that the system is set.		
g	If the tone does not cease at the pre-set time	A fault exists, re-enter the building, switch off the alarm and correct the fault before trying again.	

3.1.2 Setting the System using the Tagset or Keyswitch (if fitted)

Step	Action	Response	Display
a	Verify that all doors, etc. are closed, and that 'd' prompt is displayed		'd'
b	Place your tagset in position on the tagset module, or insert your key and turn from the 'NORMAL' position to the 'ON' position, and back again.	Display will show a single 'bar' (flashing if PART set). After a few seconds, a steady tone will commence (silent if part setting).	'.' (flashing if PART set)
c	Remove your keyswitch and leave the building by the specified route. To set the system silently (eg at night if part of the family is asleep): press * within 2 seconds of completing step b.	Continuous tone sounds. Tone will be aborted.	'.' (flashing if PART set)
d	Then proceed as described for using the keypad.		

NOTE: The Keyswitch or Tagset can set the system only in 'FULL' or 'PART SET B' modes - NOT 'Part Set C'

3.2 Omitting Individual Zones

If the programming of your system permits it, you may omit individual zones from the system as it is being set. If this is so:

Whilst the continuous exit tone is sounding, press the number of the zone you wish to omit, followed by '#' - repeating for additional zones if required.

The first three zones omitted only will indicate after the # key has been pressed.

3.3 Unsetting the System

NOTE: deviating from the prescribed ENTRY-EXIT route before switching the alarm off will cause an alarm.

3.3.1 Unsetting the system with the Keypad

Step	Action	Response	Display
a	Enter the building by the prescribed route only	Intermittent tone will commence	'.'
b	Enter your 4-digit code, followed by #	The tone will cease	'd'

3.3.2 Unsetting the system with the Tagset or Keyswitch (if fitted)

NOTE: The system may be programmed not to accept a Tagset signal to unset if FULL set.

Step	Action	Response	Display
a	Enter the building by the prescribed route only	Intermittent tone will commence	'.'
b	Place your tagset in position on the tagset module, or insert your Key and turn from 'NORMAL' to 'ON' and back again.	The tone will cease	'd'

3.4 Action Following an Alarm

3.4.1 Cancelling a daytime alarm

An alarm may occur whilst the system is 'unset' by operating a Personal Attack switch, by the effects of a Fire, or a wiring fault. In this event;

Step	Action	Response	Display
a	Enter your 4-digit code, followed by #	The alarm will silence	Will show the number of the zone initiating the alarm, or a code indicating the nature of a system fault (see 1.2)
b	Note the information shown on the Display, investigate the cause, and advise your alarm company of any action required.		
c	Reset the system by pressing the # key		'd'

3.4.2 Unsetting following an Alarm

An automatic timer is fitted to the system to silence the external sounder after a pre-set time to minimise annoyance to neighbours, etc. The system may be reset before or after this action.

Step	Action	Response	Display
a	Enter your 4-digit code, followed by #	The alarm will silence, if not done automatically	Will show the number of the zone initiating the alarm, or a code indicating the nature of a system fault (see 1.2)
b	Note the information shown on the Display, investigate the cause, and advise your alarm company of any action required.		
c	Reset the system by pressing the # key		'd'

3.5 Chime

You may switch part of the system to provide warning of an intruder in the building whilst it is occupied, without restricting your freedom of movement.

Step	Action	Response	Display
a	Press A, followed by #	Chime now active	'd.'
b	Intruder triggers programmed zone	System 'Chimes'	'd.'
c	Intruder moves to another zone	System 'Chimes'	'd.'
d	Press #		'd.'
e	Press A, followed by #	Chime now inactive	'd'

4 Manager Functions

4.1 Accessing Manager Functions

Step	Action	Display
a	Ensure that the system is in normal mode	'd'
b	Enter Manager Code (factory pre-set 2222) followed by # The system is now in 'Manager mode' and provides access to the following functions: Set User Codes Set Manager Code Walk Test Bell Test Display Logs	'E' flashing (The Manager prompt)
c	To return to normal (day) mode, press *	'd'

4.2 Setting User Codes

Step	Action	Display
a	Decide which code is to be changed, and ensure that 'Manager prompt' is showing.	'E' flashing
b	Enter 1, followed by the number of the code to be changed, and # - eg to change Code No: 3, enter 13#	',' flashing
c	Enter your required 4-digit code, slowly and deliberately.	'E' flashing
d	To DELETE a code, enter 0000 NOTE: it is NOT possible to delete Code No. 1	
e	Return to normal (day) mode by pressing *	'd'

4.3 Setting the Manager Code

Step	Action	Display
a	Ensure that 'Manager prompt' is showing.	'E' flashing
b	Enter 15, followed by #	'.' flashing
c	Enter your required 4-digit code, slowly and deliberately.	'E' flashing
d	NOTE: it is NOT possible to delete the Manager code	

4.4 Testing the System

4.4.1 Walk Test

This function enables you to test that all the detectors are working correctly, without generating an alarm.

Step	Action	Response	Display
a	Ensure that 'Manager prompt' is showing.		'E' flashing
b	Enter 20 and #		'.'
c	Commence test by triggering one of detectors on the system.	System will 'Chime' once as detector is triggered	Zone number corresponding with that detector will be displayed
d	Continue to trigger additional detectors	System will 'Chime' once as additional detector is triggered	Zone number corresponding with that detector will be displayed, and will 'scroll' (alternate) with all zones which have previously triggered
e	At end of testing		Numbers of ALL zones triggered will be scrolling on display, even though some (or all) are now clear.
f	Press *	Returns to manager mode	'E' flashing

4.4.2 Sounder Test

Step	Action	Response	Display
a	Ensure that 'Manager prompt' is showing.		'E' flashing
b	Enter 60 and #	External alarm sounder and strobe will activate	'1' flashing
c	Press *	Sounder silenced, system returns to manager mode	'E' flashing

4.5 Displaying System Logs

The system logs contain a history of events relevant to the operation and maintenance of the system, divided in to 'Alarm' events, 'Trouble' events and 'Activations'. These are stored in chronological order, and are displayed commencing with the most recent.

Step	Action	Display
a	Ensure that 'Manager prompt' is showing.	'E' flashing
b	Enter 30 and #	Display will show a character dependant upon the type of the most recent log entry - see details below.
c	Press #	Advances to next part of log entry
d	Continue to press # and read information logged	'.' indicates end of a log entry
e	Pressing # moves to next log entry	
f	Press * (whilst '.' showing)	'E' flashing

5 System Faults

5.1 System Tamper Fault (F-1)

This indicates a fault in the wiring which requires attention by the alarm company.

5.2 System Voltage Fault (F-3)

This indicates that a fault has occurred in the system power supply or battery charging circuits, and should be reported to the alarm company.

5.3 Keypad Alarm (F-7)

Whilst not a fault, a PA or FIRE alarm generated from the keypad will be indicated as F-7, to distinguish from alarms generated by devices wired to detection zones.

Note: Castle Care-Tech Ltd. reserve the right to change the specification of this system at any time in the interests of product improvement

THIS PAGE LEFT BLANK FOR NOTES

Castle Care-Tech Ltd.
INSTRUCT-35